

# **ELFO T**

# **Electric Traction Homelift**



### **General specifications**


Normative	Machine directive 2006/42/CE - EN8141
Certification body	Bureau Veritas
Power supply	230 V monophase (+/- 5%) - 50/60 Hz
Starts per hour	30
Duty cycle	33%
Loads	300 - 400 kg
Accesses	Single – opposite/side – Triple
Speed	0,15 m/s – (0,30 m/s no CE certification)
Travel (max)	25 mt
N° stops (max)	8
N° services (max)	8
DBF (min)	0,5 m (0.35m with no display)
Shaft	Masonry or structure
Control panel	EP eprom motherboard, on top of the shaft, to be placed inside
	or outside the headroom (max 3.5 meters)
	In case of black-out, the cabin will rise or descend to the mostconvenient floor.
Emergency manoeuvre	UPS device is available (see note on UPS page 4)
Guide bracket fixing	Variable - Max 1500 mm for masonry shaft
pitch	Variable - Max 1250 mm for structure
Traction	1:1 roped
Sling	Cantilever

Distance between floors (mm)		
	2000 door opening (H)	
		*2150 -
Swing door	Masonry	**2300
	Structure	2220
Sliding door	Masonry	2350
	Structure	2410


<sup>(\*) =</sup> door jambs lateral fixation; (\*\*) = sill and lintel "L" brackets fixation



Traction unit lifting kit (for shaft with no lifting eye)







Safety gear for counterweight for installations on the slab (where underneath people have access)



Keypad to be connected at the homelift for the installation and maintenance operations.

The connector interface is available in order to use the one for the ELFO hydraulic.





#### UPS for emergency floor automatic arrival

In case of black-out the cabin will arrive at most convenient floor (considering the situation of unbalancing) and open the door.

Dimensions 405P x 205H x 145L mm

#### **Emergency manoeuvre during black-out**

#### With no UPS:

- Cabin lighting keeps working
- The push button of the lowest floor on COP will light on, the passenger has to push it and hold during all the manoeuvre
- The lift for unbalancing will go to the most convenient floor (up or down) opening the brakes of the motor (so a bump, then another, then another and so on), then will stop and the light of the lowest floor will light off.
- Arrived at the landing the "open-door" push button will light on, the passenger has to push it to have the door opened (if swing door just push the panel to exit).


#### With UPS


- Cabin lighting keeps working
- The push button of the lowest floor on COP will light on, the passenger has to push it once
- The lift for unbalancing will go to the most convenient floor (up or down) feeding the motor-Automatically, then the homelift will stop and the light of the lowest floor will light off.
- Arrived at the landing the "open-door" push button will light on, the passenger has to push it to have the door opened (if swing door just push the panel to exit).



#### **Machine room**

#### ELFO-T is machine roomless






The traction unit is installed between the guides

Cantilever sling with safety ropingpoints inspectionable from the bottom of the cabin. Cabin wall removal is no longer required




#### Control panel and maintenance console





### Load diagram

ELFO-T is available in three rated loads 250 - 400, depending on the cabin surface (250 kg/mq), as per below diagram.




Cabin Area	Rated Load
< 1,2 m <sup>2</sup>	300 kg.
< 1,6 m <sup>2</sup>	400 kg.



# Pit reactions and guide's bracket reaction

800x1200mm	Normal run	In case safety gear intervention
	N (N) 14900	N (N) 24410
300 kg	F1 (N) 1520	F1 (N) 3120
	F2 (N) 260	F2 (N) 430

1100x1400mm	Normal run	In case safety gear intervention
	N (N) 15780	N (N) 26380
400 kg	F1 (N) 2240	F1 (N) 4370
	F2 (N) 400	F2 (N) 670




## **Power supply**

Nominal electric power input	300 kg	400 kg
Nominal input absorption 0.15m/s (0.30)	5,0 A (7.5)	5,5 A (9)
Rated power 0.15m/s (0.30)	1.1 Kw (1.7)	1,2 Kw (2)



#### **Electrical diagram**



#### Keys:

- A Breaker
- B Power supply board
- 1 Differential-Magnetothermic switch monophase 2 x 25 A type B, idn 0.03-A\*\*
- 2 Differential-Magnetothermic switch monophase power supply controlpanel 2 x 16 A
- 3 Differential-Magnetothermic switch monophase for potential power supplyof the cabin (Lighting or door operator 2 X 16 A)
- 4 Differential-Magnetothermic switch monophase 2 x 10 A for potential shaftlighting and XS sockets\*\*
- XS 2P+T 10 A 230V sockets in the shaft \*\*
- D Shaft lighting switch (in case it is provided)
- S Breaker auxiliary contacts of the control panel (2) to break the batteries and UPS (if provided).
- \*\* The size of the breaker has to be evaluated by the installer in function of any additional power absorption caused by eventual devices not provided by the supplier.



#### Pit and headroom dimension

#### Pit Depth:

in function of the cabin area/rated load 150 or 190mm (see the scheme at page 7)

NB: add 20mm for flooring by the customer (max 20mm, max 50Kg)

Headroom: (for cabin height 2100mm)


Cabinet outside the shaft – swing door + IR barrier	mm	2350
Cabinet outside the shaft – swing door + bus door	mm	2450
Cabinet outside the shaft – sliding door	mm	2550
Cabinet inside – masonry	mm	2650
Cabinet inside – structure	mm	2730


#### Manoeuvre:

L.O.P always	Automatic
C.O.P without cabin door (CE certification)	Hold to run
C.O.P without cabin door (no CE certification)	Automatic
C.O.P Cabin door	Automatic




# 2 Panel sliding door






(a)= Rooms are 20mm, but could be less, refer to final drawing.

(b)= Lintel could be 210 or 100mm; please refer to final drawing






# 3 Panel sliding door




(a)= Rooms are 20mm, but could be less, refer to final drawing.

(b)= Lintel could be 210 or 100mm; please refer to final drawing











# Swing door







(a)= Rooms are 20mm, but could be less, refer to final drawing.

(b)= In case of FACE automatic door opener the lintel is 140mm
















#### Swing door - Masonry



Pag. **18** di 19




#### **Swing door - Structure**






#### Swing door + bus door - Masonry





### **Swingdoor + folding door - Structure**






#### Sliding door 2 panels - Masonry







#### Sliding door 2 panels - Structure








#### Sliding door 3 panels - Masonry


























Pag. **24** di 19





### Sliding door 3 panels - Structure

























#### E.P. Elevatori Premontati srl

Tel. +39 050 875091

www.epelevators.com - info@epelevators.com